

## How to Change Bit Depth in LASX Software

**11/15/17** 

1. Click Configuration.



## 2. Click Hardware.



- 3. Under Resolution you will see Bit Depth.
- 4. The drop down menu allows you to change the Bit Depth. Note: 16 Bit Depth will only work when in photon counting mode.

